

KENTUCKY TRANSPORTATION CABINET

Kentucky TRNS*PORT Information Series

SiteManager Materials Module

Tester Qualifications Window

Navigation

Main Panel \ Materials Management \ Approved Lists \ Tester Qualifications

General Description

The Tester Qualifications window displays testing personnel and qualification information.

Procedure

In KYTC, the Tester Qualifications window will display all testers and their qualifications. The Tester Qualifications window will be loaded through an interface from KQTL to SiteManager.

All modifications made to this window should be done by the KQTL to SiteManager interface.

The SiteManager System Administrator will have update access to the Tester Qualifications window. All other SiteManager Users will have Inquiry Access to the Tester Qualifications window.

Field Table

Field Name	KYTC Population Policy & Procedure
User ID	Displays the unique identification number assigned to each user entered as a tester in the system. - This will be maintained via the KQTL-SM Interface.
Name	Displays the full name of the Tester. Format will be Last Name, First Name, MI (Mixed Case).
Geographic Area	Displays the geographic area in which the testing person is located. - KYTC will not be using this field.
SM User	An indicator that displays whether the user is a SiteManager user or not.
Tester	An indicator that displays whether the user is an active Tester or not. - This will be maintained via the KQTL-SM Interface.
Sampler	An indicator that displays whether the user is an active Sampler or not. - This will be maintained via the KQTL-SM Interface.
Global Tester	An indicator that displays whether the user is a Global Tester or not. - KYTC will not use this field.

KENTUCKY TRANSPORTATION CABINET

Kentucky TRNS*PORT Information Series

SiteManager Materials Module

Field Name	KYTC Population Policy & Procedure
Type	Displays the type of qualification. In KYTC, this is the type of materials the tester is qualified to test (e.g. Aggregate). - This will be maintained via the KQTL-SM Interface.
Level	Displays the level of qualification. In KYTC this is the KQTL Course Subject taken by the tester. - This will be maintained via the KQTL-SM Interface.
Authority	Displays the authority by which qualification was judged. In KYTC, this will value will be KYTC. - This will be maintained via the KQTL-SM Interface.
Effective Date	Displays the date the qualification became effective. - This will be maintained via the KQTL-SM Interface.
Expiration Date	Displays the date the qualification expires. - This will be maintained via the KQTL-SM Interface.
Active Indicator	Displays if the tester qualification is currently active ("Y"), will be active in the future (" "), or is not active ("N"). Display only.
Test Method	Displays the qualified Test Method(s) allowed via the specified qualification. - This will be maintained via the KQTL-SM Interface.
Test Description	Displays the description of the Test.

GENERIC FIELDS WINDOW

Generic Fields Window Description

The Generic Fields Window allows for the viewing of generic user data on to the Material User (e.g., Tester) record. This data can be used for agency specific purposes beyond those supplied by the SiteManager base product.

This data is shared between the Material User window, the Sampler Qualification window, and the Tester Qualification window for each user. The data is fully editable when accessed from the Material User window, but it is inquiry-only on both of the qualification windows.

Procedure

Generic Fields should be entered into SiteManager in accordance with the field table definitions below.

In KYTC, the Generic Fields window on the Tester Qualification window will not be used. It will not be populated from KQTL.

KENTUCKY TRANSPORTATION CABINET

Kentucky TRNS*PORT Information Series

SiteManager Materials Module

REMARKS WINDOW

Remarks Description

The Remarks window outlines specific information that describes free form remarks for the current material user.

This data is shared between the Material User window, the Sampler Qualification window, and the Tester Qualification window for each user. The data is fully editable when accessed from any of these windows.

Procedure

In KYTC, the Remarks window on the Material Detail window should be populated in accordance with the field table definitions below.

In KYTC, the Remarks window on the Tester Qualification window will not be used. It will not be populated from KQTL.

ADDRESS WINDOW

Address Description

The Address window outlines specific information that describes the material user, including the locations the user can be found.

This data is shared between the Material User window, the Sampler Qualification window, and the Tester Qualification window for each user. The data is fully editable when accessed from the Material User window, but it is inquiry-only on both of the qualification windows.

Procedure

In KYTC, the Address window on the Tester Qualification window will not be used. It will not be populated from KQTL.