
Sometimes it is necessary to supplement survey data with other methods of existing ground data. If we perform a field survey of our project but still require more data to complete our existing ground model, we can supplement the field survey data with data from a DEM or LiDAR. These forms of existing ground data are lower quality than the field survey, but they will allow us to generate decent ground information.

To begin, create **A COPY** of the field survey data as well as the LiDAR information we will be adding.


File Surface Geometry			
	<u>D</u> rainage <u>E</u> va	aluation <u>N</u>	<u>l</u> odeler Dr <u>a</u> ftii
		Data Ty	pe
Surfaces		J∩ Brea	kline Fe
Default		Section 201	tour Fea
uose Fill/	Save		ior Feat
E - S Liddi	Save As		red Brea ior Feat
	Set Active		lom Fea
			e Points
	Triangulate		igles
	Copy.		
	Close		
	Empty		
	Properties		
-			1
Sentley InRoads V8i (SELECTseries	2)		
Copy Surface			Quantities
rom		Apply	Active
ame: 1059 FINAL EX SURFA	ACE 🔻	Close	3061
· · · · · · · · · · · · · · · · · · ·	CE	Close	
escription: 1059 FINAL EX SURFAG			
		Help	184
eference: Default		Help	184
o		Help	184 0 0 154
eference: Default o ame: 1059 FINAL EX SURFA		Help	184 0 0 154 4
ference: Default me: 1059 FINAL EX SURFA scription: for merge with LiDAR		Help	184 0 0 154
reference: Default o ame: 1059 FINAL EX SURFA		Help	184 0 0 154 4
eference: Default mme: 1059 FINAL EX SURFA scription: for merge with LiDAR		Help	184 0 0 154 4

If we were to merge the two surfaces now, we would likely see very abrupt changes in elevations between the two surfaces along this exterior boundary line due to some subtle differences between the elevations of the field data and the supplemental data. To account for these differences, it is advisable provide a "buffer" area between the two data sets. To do this, we can offset the exterior boundary of the field data by a set distance; that distance could be 5', 10', 20' or more. The distance you offset will be dependent on the severity of the elevation difference at the boundary. The lower the offset value, the more "accurate" your merged surface data will be. The purpose of the "buffer" area is to provide a small transition region between the elevations of the field survey and the elevations from the supplemental data.

The next step is to view the exterior boundary of the field survey data in our DGN file.









Next, select a value for the offset of the field survey boundary and perform the offset. For the example, 10' we will be used.


20 PR Manu 05-1059.00 channel change with 45 ^ skew.dgr									
R_PL_PSH_PR → 🛃 83 ▼ 🔂 0 ▼ 🗐 1									
: <u>Fi</u> le <u>E</u> dit Element <u>S</u> ettings <u>T</u> ools <u>U</u> tilities Workspace									
Tasks 👻 🕂 🗙									
V Drawing									
Drawin 2 Move									
Q 🧐 🧭 🧾 Scale									
W . Kotate									
E O O A Mirror									
R 2 0 0 6 Array									
T 🗈 🕉 📴 Z Align Elements By Edge									
A A 8 Stretch									
AI AI A2 2 9 Move Parallel									
S 🔆 🗱 🕞 👲 Move To Contact									
D Open 'Manipulate' as Toolbox									
THR STAR									

8/21/2014



The offset boundary can create sharp points or cross itself and create loops. If this is discovered, it can be edited manually by moving or deleting vertices to get a boundary that is more reasonable.






We can now import the offset line into our field survey surface. In InRoads, go to **File>Import>Surface**.

le Surface Geometry Drainage Evaluation Modeler Drafting Quantities Tools Help									
<u>New</u>	Ctrl+N	Deleted	Total	Blocks	Min Northing	Min Easting	Min Elevation	Max Northing	
Den	Ctrl+O	750	3811	1	4005574.89	5150700.04	658.1280	4006135.83	
Save	•	0	0	0	0.00	0.00	0.0000	0.00	
Save As		4	188	1	4005574.89	5150669.27	659.7930	4006135.83	
<u>C</u> lose	,	0	0	0	0.00	0.00	0.0000	0.00	
ProjectWise Organizer Project Defaults		0	0	0	0.00	0.00	0.0000	0.00	
Project Options		754	908	1	3952121.51	5150593.05	661.9010	4006198.67	
		0	4	1	3952111.51	5150583.05	648.1280	4006208.67	
Text Import Wizard		190	1768	1	0.00	0.00	0.0000	0.00	
Import	•	Surface							
Export	•	👗 Slaface Adva	nced						
Translators	•	Here Geometry							
1 pw:\\KYTCP00W02.kytc.ds.ky.gov:KYTC-Main\\InRoads Files\Lidar.dtm		LAS Data							
2 pw:\\KYTCP00W02.kytc.ds.ky.gov:KYTC-Main\\InRoads Files\KYTC_Civil_V8i.xin									
3 pw:\\KYTCP00W02.kytc.ds.ky.gov:KYTC-Main\\InRoads Files\KYTC Components.itl									
4 pw:\\KYTCP00W02 kytc.ds.ky.gov:KYTC-Main\\InRoads Files\DefaultTemplates.itl									
5 pw:\\KYTCP00W02.kytc.ds.ky.gov:KYTC-MainDocuments\\In Roads Files\1059 Modeler File Join	Inspection.ird								
<u>6</u> pw:\\KYTCP00W02.kytc.ds.ky.gov:KYTC-Main\\InRoads Files\1059 Joint Inspection.alg									
7 pw:\\KYTCP00W02.kytc.ds.ky.gov:KYTC-Main\\InRoads Files\1059 FINAL EX SURFACE.dtm									
8 pw:\\KYTCP00W02kytc.ds.ky.gov:KYTC-Main\\InRoads Files\templates.itl 9 pw:\\KYTCP00W02kytc.ds.ky.gov:KYTC-Main\\InRoads Files\Merge Ex + DEM.dtm									
2 pw:\\KYTCP00W02.kytc.ds.ky.gov:KYTC-Main\\InRoads Files\Merge EX + DEM.dtm 10 pw:\\KYTCP00W02.kytc.ds.ky.gov:KYTC-Main\\InRoads Files\Mainline 8_6.dtm									

Under "Surface", select your field survey surface; this is where it will place the imported feature. We will "Load From" Single Element and give the feature "Elevations" by Drape Surface. The "Intercept Surface" should be set to the supplemental data surface. Give the feature a Name and Feature Style and set the Point Type to Exterior.

Manager Import Surface			, • 💌				
From Graphics DEM F	rom Geometry						
Surface: 10	1059 FINAL EX SURFAC - Appl						
Load From: Sin	gle Element	•	Filter				
Level: 0			Results				
Elevations: Dra	ape Surface	▼ Pre	ferences				
Intercept Surface:	ar Copy	_					
Drape Vertices Only			Help				
Thin Surface							
Tolerance: 0.0	0.00						
Features	s Information						
Seed Name:	buffer		→ +				
Feature Style:	Exteri	or Boundary	•				
Point Type:	Exteri	or	•				
Maximum Segmen	t Length: 0.00						
Point Density Inter	val: 0.00						
Duplicate Names:							
Exclude from Triangu	lation						
	Close						

To import the offset line, click **Apply** and select the offset line in the DGN view.



This has placed the offset feature, with elevations from the supplemental data, in our copy of the field survey data.

🕌 Feature Pro	operties						- • •
Surface: Feature:	1059 FINAL EX SURFA	CE 🔻		Style Available:			Apply
Feature: Name TOS189 TOS193 TOS214 TOS224 TOS229 TOS229 TOS248 TRDNC WIW WIW159 WIW159 WIW159 WIW162 WIW168 WMDNC WVDNC buffer ext	Style TOS TOS TOS TOS TOS TOS TOS TOS TR WIW WIW WIW WIW WIW WIW WIW WIW WIW WI	Top of Slope Top of Slope Top of Slope Top of Slope Top of Slope Top of Slope Top of Slope Trees Wing Wall Wing Wall Wing Wall Wing Wall Wing Wall Wing Wall Wing Wall Water Meter Water Valve	• +	Available: A A ABUT AP APAD As-Built Surface BCCMP Primary: EX Breakline Secondary: Pay Items Name	Description	From Style	Close Filter Edit Style New Style List Points Help
Name: Description: Parent: V Refresh/Dis	buffer play in 3-D/Plan View		▼	Triangulation Feature Type: Point Density In Exclude from Tr	0.00	•	

Next, re-trinagulate the field survey surface to reflect the new changes.

🚔 Bentley InRoads V8i	(SELECTseries 2)	
<u>File</u> <u>S</u> urface <u>G</u> eome	try <u>D</u> rainage <u>E</u> valuation <u>M</u> od	le
	D)a
□ Surfaces	7	r
😥 🥌 Default		2
🛓 🚭 Lidar Copy	/	2
🗄 🚔 1059 FINA	L EX SURFACE COPY	k
	Save	2
	Save As	t.
	Set Active	
	Triangulate	
	Copy	
	Close	
	Empty	
	Properties	
surfaces 品 Ge	eometry 😭 Pref 🔹 🗸	[

Now we can merge the two surfaces together. In InRoads, select **Surface>Design Surface>Merge Surfaces**.

<u>F</u> ile	<u>S</u> urfa	ice	<u>G</u> eometry	<u>D</u> rainage	Evaluation	Mo	deler	Dr <u>a</u> fting	<u>Q</u> uantities	<u>T</u> ools	<u>H</u> elp	
	View Surface					•	Data	Гуре		Acti	ve	
		Update <u>3</u> -D/Plan Surface Display					T Breakline Fe			5095		
	Fit <u>S</u> urface					~	ntour Fea			0		
	🔀 Iriangulate Surface						erior Feat		1	84		
	0	Desig	n Surface			•	nf 🖉	erred Brea	a		0	
	E	dit S	Surface			+	Я	Copy Single	e Feature			
	E	eatu	ire			•		dit Feature				
	Surface Properties					C		ture Points				
	Active Surface				_	_ ✓ Divide Feature ♀/ Reverse Feature Direction						
	Z 0	ору	Surface				X Delete Feature					
	¥ [<u>)</u> elet	e Surface				X Partial Delete					
	18 E	Rena	me Surface			+ŧ <u>B</u> reak Feature						
	ļ	<u>J</u> tilitie	s			•	H	oin Featur	es			
1						T	<u>×</u> 1	Frim <u>F</u> eatur	es			
							12 A S	Extend Fea				
							1 J 1	ntersect Fe				
1 📾 🤋	Surfac	es	ය Geon	netry 📋 🛅	Pref 🕢 🔸				n of S <u>u</u> rface			
Combi	nes tv	vo si	urfaces					<u>M</u> erge Surf Fransform \$		ar -		
							100	-			_	
								Delete <u>T</u> ria	-			
									ngles By Filte			
							Y∳ (nange In	angle Edge	-		

The **Original** surface needs to be set to the surface containing your supplemental information. The **Design** surface is the surface that has your field survey data and the offset feature. The **Destination** surface needs to be selected or you can type a name in the field and it will create the surface for you. Usually, the only toggle you need on is the **"Add Design Surface Edge as Breakline**" toggle. To learn more about all the toggles, view the Bentley help documentation. Select all the features you want to merge from the field survey surface into the new combined surface (usually you want all of the features) and select **Apply**.

📸 Bentley InRoads	V8i (SELECTseri	ies 2)	
Merge Surfaces			
Retain Features	-	angulation	Apply Close Filter Preferences Help
Name	Style	Descriptio	n 🔺 🕈
BLD BMDNC BOS BOS175 BR DP125 Duplicate Names:	BLD BM BOS BOS BR DB	Building Benchmarl Bottom of 3 Bridge (Ro Bridge (Po	k Slope Slope adway)

You have created a merged surface with a smooth transition between the field survey data and the supplemental data. If you have any questions on this process, please contact the KYTC Highway Design Developmental Branch at 502-564-3280.