


Transferring a Calibration from One Job to Another Job

Introduction The GPS site calibration process establishes the relationship between the WGS-84 positions determined by GPS observations and the local coordinates defined by a local map grid with elevations above sea level. A local map grid can be a published one, such as a UTM zone or an arbitrary system such as a grid system with the origin N10000, E5000, E100.

There are instances when you would like to use an already existing calibration with another job.




In this guide, we will transfer a calibration from an existing job to a new job. The job that contains the calibration is called OldJob and we will transfer this calibration to a new job titled NewJob.

Note: This guide was written using Survey Controller version **12.10**. If you are using a different version, the screens below may be different than what you are seeing. Older versions of Survey Controller create a new destination job during the copying process. Newer versions require an existing destination job.

Step	Action	Display
1	<ul style="list-style-type: none"> • Turn on the TCS2 controller. <p>On the TSC2 controller:</p> <ul style="list-style-type: none"> • Tap on Survey Controller from the Windows screen. <p>This step continues on the following page</p>	



Continued on the following page

Transferring a Calibration from One Job to Another Job, *continued*

Step	Action	Display
<p>1</p>	<p>This step continues from the previous page:</p> <p>The Trimble Survey Controller start-up splash screen is displayed. Notice the version number is displayed.</p> <p>This starts the Trimble Survey Controller program and takes you to the main menu.</p>	
<p>2</p>	<p>From the Main menu of the Trimble Survey Controller program:</p> <ul style="list-style-type: none"> • Tap on the Files icon. <p>This opens a pop up menu.</p>	
<p>3</p>	<p>From within the pop up menu:</p> <ul style="list-style-type: none"> • Tap on Copy between jobs. <p>This takes you to the Copy between jobs screen.</p>	


Continued on the following page

Transferring a Calibration from One Job to Another Job, *continued*

Step	Action	Display
4	<p>In the Copy between jobs screen:</p> <p>In this screen we select the source job, the destination job, and what we wish to copy. To select the source job,</p> <ul style="list-style-type: none"> Tap on the Job to copy from field's down arrow. <p>This opens a pull-down menu.</p>	
5	<p>From within the pull-down menu:</p> <ul style="list-style-type: none"> Tap on the source job. <p>Note: In this example the source job is called OldJob. You may be using a different job.</p> <p>To select the Destination job:</p> <ul style="list-style-type: none"> Tap on the Job to copy to field's down arrow. Select the destination job from the pull-down menu. <p>Note: In this example the destination job is called NewJob. You may be using a different job.</p> <p>This step continues on the following page.</p>	

Continued on the following page

Transferring a Calibration from One Job to Another Job, *continued*

Step	Action	Display
<p data-bbox="277 432 293 457">5</p> <p data-bbox="370 432 735 499">This step continues from the previous page:</p> <p data-bbox="370 579 805 718">In the Copy field we can select exactly what we wish to copy between jobs. In this example we are just copying the calibration.</p> <ul data-bbox="418 764 829 1054" style="list-style-type: none"> • Tap on the Copy field's down arrow. • Select Calibration from the pull-down menu. • Tap on the Accept button when finished. <p data-bbox="370 1134 841 1272">This copies the calibration to the job titled NewJob, closes the Copy between jobs screen, and returns you to the main menu screen.</p>		

Congratulations You have just copied an existing calibration to another job.