

Boyle County-Stuart Powell Field KDVK

Danville, Kentucky USA

Lat/Long: 37-34-39.2705N 084-46-10.1922W
37-34.654508N 084-46.169870W
37.5775751,-84.7694978
(estimated)

Elevation: 1022 ft. / 311.5 m (surveyed)

3D View:

RWY 13 [Google Earth](#) RWY 31 [Google Earth](#)

RWY 1 [Google Earth](#) RWY 19 [Google Earth](#)

For Additional Airport Information:

[AirNav: KDVK - Stuart Powell Field Airport](#)




Airport Communications:

CTAF/UNICOM: 122.8

WX AWOS-3: 128.325 (859-854-0058)

LEXINGTON APPROACH: 120.15

LEXINGTON DEPARTURE: 120.15



Airport Services:

Fuel available:	100LL JET-A+
Parking:	hangars and tiedowns
Airframe service:	MAJOR
Powerplant service:	MAJOR
Bottled oxygen:	NONE
Bulk oxygen:	NONE

Airport Operations:

Airport use: Open to the public
Activation date: 04/1941
Control tower: no
ARTCC: INDIANAPOLIS CENTER
FSS: LOUISVILLE FLIGHT SERVICE STATION
NOTAMs facility: LOU (NOTAM-D service available)
Attendance: 0800-1800
Wind indicator: lighted
Segmented circle: yes
Lights: ACTVT REIL RWY 31; PAPI RWY 13 & 31; MIRL RWY 13/31 - CTAF.
Beacon: white-green (lighted land airport)
Operates sunset to sunrise.

Ground Transportation:

Courtesy Car:
Shuttle:
Uber / Lyft:
Taxi:
Rental:

Airport Contact Information:

Phone: 859-854-5994
Airport Manager: Christian Barker
Email: Board@danvilleairport.com

Airport Accommodations / Area Attractions:

[Danville-Boyle County Airport \(danvilleairport.com\)](http://danville-boyle-county-airport.com)

Airport Comments: