

Breckinridge County, I93

Hardinsburg, Kentucky USA

Lat/Long: 37-47-05.3000N 086-26-28.6000W
37-47.088333N 086-26.476667W
37.7848056,-86.4412778
(estimated)

Elevation: 732.1 ft. / 223.1 m (surveyed)

3D View: RWY 10 [Google Earth](#) RWY 28 [Google Earth](#)

For Additional Airport Information:

[AirNav: I93 - Breckinridge County Airport](#)




Airport Communications:

CTAF: 122.9

LOUISVILLE APPROACH: 132.075

LOUISVILLE DEPARTURE: 132.075



Airport Operations:

Airport use: Open to the public

Activation date: 04/1968

Control tower: no

ARTCC: INDIANAPOLIS CENTER

FSS: LOUISVILLE FLIGHT SERVICE STATION

NOTAMs facility: LOU (NOTAM-D service available)

Attendance: UNATNDD

Wind indicator: lighted

Segmented circle: no

Lights: ACTVT REIL RYS 10 & 28; PAPI RYS 10 & 28;
MIRL RY 10/28 - 122.9.

Beacon: white-green (lighted land airport)

Operates sunset to sunrise.

Airport Services:

Fuel available: 100LL

Parking: tiedowns

Airframe service: NONE

Powerplant service: NONE

Bottled oxygen: NONE

Bulk oxygen: NONE

Ground Transportation:

Courtesy Car:

Shuttle:

Uber / Lyft:

Taxi:

Rental:

Airport Contact Information:

Phone: 270-456-6062

Airport Manager:

Email: breckinridgeairport@gmail.com

Airport Accommodations / Area Attractions:

[AirNav: I93 - Breckinridge County Airport](#)

Airport Comments: