

Georgetown-Scott County Regional 27K

Georgetown, Kentucky USA


Lat/Long: 38-14-03.9630N 084-26-04.8610W
38-14.066050N 084-26.081017W
38.2344342,-84.4346836
(estimated)

Elevation: 947.7 ft. / 288.9 m (surveyed)

3D View: RWY 3 [Google Earth](#) RWY 21 [Google Earth](#)

For Additional Airport Information:

[AirNav: 27K - Georgetown-Scott County Regional Airport](#)



Airport Communications:

CTAF/UNICOM: 123.0

WX AWOS-3: 119.975 (502-867-1564)

LEXINGTON APPROACH: 120.15 ;040-220 120.75 ;221-039

LEXINGTON DEPARTURE: 120.15 ;040-220 120.75 ;221-039

CLEARANCE DELIVERY: 127.425

WX ASOS at LEX (14 nm SW): PHONE 859-281-5700

Airport Operations:

Airport use: Open to the public

Activation date: 04/1993

Control tower: no

ARTCC: INDIANAPOLIS CENTER

FSS: LOUISVILLE FLIGHT SERVICE STATION

NOTAMs facility: LOU (NOTAM-D service available)

Attendance: SAT 0800-1800, ALL SUN 0900-1700, ALL MON-FRI
0800-1900

Wind indicator: lighted

Segmented circle: yes

Lights: ACTVT REIL RWY 03/21; PAPI RWY 03/21; MIRL
RWY 03/21; WINDSOCK - CTAF.

Beacon: white-green (lighted land airport)
Operates sunset to sunrise.

Airport Services:

Fuel available: 100LL JET-A+

100LL:FUEL AVBL 24/7 WITH CC.

Parking: hangars and tiedowns

Airframe service: MAJOR

Powerplant service: MAJOR

Bottled oxygen: HIGH

Bulk oxygen: NONE

Ground Transportation:

Courtesy Car:

Shuttle:

Uber / Lyft:

Taxi:

Rental:

Airport Contact Information:

Phone: 502-863-6320

Airport Manager: James Toole

Email: admin@flygeorgetown.com

Airport Accommodations / Area Attractions:

[Georgetown Scott County Regional Airport](#)

georgetownscottcountyairport.com

Airport Comments: