

# Hopkinsville-Christian County KHVC

Hopkinsville, Kentucky USA

**Lat/Long:** 36-51-25.1000N 087-27-18.3000W  
36-51.418333N 087-27.305000W  
36.8569722,-87.4550833  
(estimated)

**Elevation:** 563.5 ft. / 171.8 m (surveyed)

**3D View:** RWY 8 [Google Earth](#) RWY 26 [Google Earth](#)

**For Additional Airport Information:**

[AirNav: KHVC - Hopkinsville-Christian County Airport](#)



## Airport Communications:

CTAF/UNICOM: 122.8

WX AWOS-3: 132.575 (270-886-6311)


CAMPBELL APPROACH: 118.1

CAMPBELL DEPARTURE: 118.1

BASIC RADAR: 118.1

WX ASOS at CKV (14 nm S): 134.575 (931-431-3045)

WX AWOS-3 at EOD (17 nm S): PHONE 270-956-3100



## Airport Operations:

Airport use: Open to the public

Activation date: 11/1952

Control tower: no

ARTCC: MEMPHIS CENTER

FSS: LOUISVILLE FLIGHT SERVICE STATION

NOTAMs facility: LOU (NOTAM-D service available)

Attendance: 0800-1700

Wind indicator: lighted

Segmented circle: yes

Lights: ACTVT REIL RWY 08/26; PAPI RWY 08/26 AND

MIRL RWY 08/26 - CTAF

Beacon: white-green (lighted land airport)

Operates sunset to sunrise.

## Airport Services:

Fuel available: 100LL JET-A+

Parking: hangars and tiedowns

Airframe service: MINOR

Powerplant service: MINOR

## Ground Transportation:

Courtesy Car:

Shuttle:

Uber / Lyft:

Taxi:

Rental:

## Airport Contact Information:

Phone: 270-887-4157

Airport Manager:

Email: [hopkinsvillechristiancoa@gmail.com](mailto:hopkinsvillechristiancoa@gmail.com)

## Airport Accommodations / Area Attractions:

[Hopkinsville - Christian County Airport - Hopkinsville, KY](#)

[hopkinsville-christiancoairport.com](http://hopkinsville-christiancoairport.com)

## Airport Comments: