

Ohio County KJQD

Hartford, Kentucky USA


Lat/Long: 37-27-30.7720N 086-50-59.3670W
37-27.512867N 086-50.989450W
37.4585478,-86.8498242
(estimated)

Elevation: 537 ft. / 163.7 m (surveyed)

3D View: RWY 3 [Google Earth](#) RWY 21 [Google Earth](#)

For Additional Airport Information:

[AirNav: KJQD - Ohio County Airport](#)



Airport Communications:

CTAF/UNICOM: 122.8
WX AWOS-3PT: 132.1 (270-298-7936)
EVANSVILLE APPROACH: 124.025
EVANSVILLE DEPARTURE: 124.025
APCH/DEP SVC PRVDD BY INDIANAPOLIS ARTCC ON FREQS
128.3/284.65 (EVANSVILLE RCAG) WHEN EVANSVILLE APCH CTL CLSD.

Airport Operations:

Airport use: Open to the public
Activation date: 06/1984
Control tower: no
ARTCC: INDIANAPOLIS CENTER
FSS: LOUISVILLE FLIGHT SERVICE STATION
NOTAMs facility: LOU (NOTAM-D service available)
Attendance: MON - FRI 0900-1700
SVC AFT HR - AMGR.
Wind indicator: lighted
Segmented circle: yes
Lights: DUSK-DAWN ACTVT PAPI RWY 03 & 21; MIRL RWY
03/21 - CTAF.
Beacon: white-green (lighted land airport)
Operates sunset to sunrise.

Airport Services:

Fuel available: 100LL
Parking: hangars and tie-downs
Airframe service: MAJOR
Powerplant service: MAJOR
Bulk oxygen: NONE
Fuel available: 100LL

Ground Transportation:

Courtesy Car:
Shuttle:
Uber / Lyft:
Taxi:
Rental:

Airport Contact Information:

Phone: 270-993-0867
Airport Manager:
Email: 7k4airport@gmail.com

Airport Accommodations / Area Attractions:

[Ohio County Kentucky Airport - KJQD - Home](#) | [Facebook](#)

Airport Comments: