

ORD Support Log

<u>Issue</u>	<u>Solution/Comment</u>	<u>Version</u>	<u>Date Reported</u>	<u>Priority</u>	<u>Date Fixed</u>
All scales of Proposal cross sections are shifted off the sheet.	Correct all shifted Drawing boundary's in the proposal sheet seeds.	10.09.00.91	7/30/2021	High	8/2/2021
Update to SUDA seed files the files have been renamed	Replace the two Suda seed files	10.09.00.91	8/5/2021	High	8/5/2021
SUDA files not found	Update the KYTC_Standards_OC.cfg and replace in Test workspace	10.09.00.91	8/5/2021	High	8/6/2021
Contours display on default level for PR Contour Main	Feature Definitions -Linear- Terrain PR Boundary, Pr Contour Intermediate, Pr Contour Min had no Linear Feature Symbology assigned . Assign proper Linear Feature Symbology.	10.09.00.91	8/9/2021	High	8/10/2021
Update Standards Crashing Machine	Item Types have different instances of KYTC_Item_Types Library. Set KYTC_Standards_OC.cfg to point to KYTC_Features_Levels_Element Templates_Annotations.dgnlib	10.09.00.91	8/11/2021	High	8/16/2021
First Gen KYTC Typical Section Sheet is missing the COUNTY, ITEM, SHEET Heading	Remove text from First Gen KYTC Sheet Directory.dgnlib and add the headings to First Gen KYTC Sheet Reference. Dgn	10.09.00.91	7/22/2021	High	7/22/2021
Need 10 scale profile for pipe sheets	Create Pipe Grid 10 Scale 50 Stationing and Pipe Grid 10 Scale 50 Stationing Annotation Definitions	10.09.00.91	8/5/2021	High	8/17/2021
Add Links to Workflows to Workspace	Add Multiple links to workspace for workflows KYTC_Interface.dgnlib	10.09.00.91	8/26/2021	High	8/27/2021