


Adding an Item to the Favorites Menu

Introduction

The Favorites menu provides quick access to commonly used screens and to various commands when connected to a conventional instrument or GPS receiver. This can reduce the number of button pushes required to access a commonly used screen. Using this function will create a "shortcut" to a particular screen or command.

In this example you will learn how to create a favorite (shortcut) that will access the Bluetooth screen using a minimum of button presses.




Continued on the following page






Adding an Item to the Favorites Menu, continued



Continued on the following page



Adding an Item to the Favorites Menu, continued



Continued on the following page



Adding an Item to the Favorites Menu, continued

Congratulations

You have just completed creating a shortcut using the favorites menu.

